

MHT-H HOT TAPPING MACHINE

OPERATION & MAINTENANCE MANUAL COVERING MODELS

MHT824-H, MHT1236-H and MHT1242-H

Doc: MML265

Issue: 004



Version History

All Mirage Machines Ltd. documentation is quality controlled and audited in accordance with **BS EN ISO 9001:2008**; the scope of which covers design, manufacture and repair of in-situ machine tools.

Version No.	Implemented By	Revision Date	Approved By	Approval Date	Comments
4	STH	19/10/2020	DMS	19/10/2020	Updated GA drawings.
5	STH	21/10/2020	JB/DMS	21/10/2020	Added warning note regarding over feeding using autofeed options
6	STH	03/11/2020	DMS	03/11/2020	Measuring cutting speed guidance added to page 19
7	STH	12/2020	-	-	Rebrand

Operation & Maintenance Manual Approval

The undersigned acknowledge they have reviewed this initial Machine Operation & Maintenance Manual and agree with the approach it presents. Changes to this Operation & Maintenance Manual will be coordinated with, and approved by, the undersigned or their designated representatives.

Approver 1			
Signature:		Date:	24/03/2020
Print Name:	Shailini Thompson		
Title:	Technical Writer		
Approver 2			
Signature:		Date:	24/03/2020
Print Name:	Dan Stephens		
Title:	Engineering Manager		



Contents

1.	Introduction	4
1.1.	Overall Equipment Description	4
2.	Health and Safety	5
2.1.	Mandatory Safety Signs (for the purpose of trials at Enerpac)	5
2.2.	Machine Hazards Signs	6
2.3.	Safety Procedures	6
2.3.1.	Pre-Operational Safety Checks	7
2.4.	Operational Safety Checks	7
2.4.1.	Housekeeping	7
2.4.2.	Potential Hazards	7
3.	Handling	7
4.	Machine Specification	8
5.	Installation	9
5.1.	Fitting Cutters & Pilot Drills	9
5.2.	Lifting	15
5.3.	Securing to pipeline	17
5.4.	Service and Supplies	17
5.4.1.	Personnel	17
6.	Machine Operation	18
7.	Completion Plug Installation Guidance	21
8.	Machine Maintenance	26
8.1.	Maintenance	26
8.2.	Seal Replacement Procedure	27
8.2.1.	Replacing the spool seal	27
8.2.2.	Replacing the drawbar seal	29
9.	Troubleshooting Guide	31
10.	General Assembly Drawings	32
11.	Appendices	79
11.1.	Hot Tapping Data Sheet	79
11.2.	Recommended torque settings for fasteners	80
11.3.	Ladder (Optional Accessory)	81
11.3.1.	Installation	82
11.4.	Skid (Optional Accessory)	84
11.4.1.	Installation	85
11.5.	Alternative Gearbox assembly (MHT1242-34)	87
11.6	General Notes	20

Doc: MML265

Issue: 004




1. Introduction

1.1.Overall Equipment Description

The MHT hot tapping machine range is used to make connections & branches into pipelines without the need for a shutdown procedure.

The machine range has been designed to cover the machining of $\emptyset 8" - \emptyset 42"$ holes in various material pipelines & vessels. They are hydraulically operated with industry standard boring bar connection and a range of flange adapters to accept current hot tapping tooling.



Doc: MML265

Issue: 004



2. Health and Safety

Enerpac has made every effort to ensure that the Information given in this Operation & Maintenance manual, and other publications relating to this machine is correct and understandable. However it is acknowledged that there may be errors or omissions in this publication.

The company also reserves the right not to provide updates, corrections or amendments to this publication but will endeavour to keep its customers up to date with all changes that may affect the machine operation or safety.

2.1. Mandatory Safety Signs (for the purpose of trials at Enerpac)

ISO 7010 SYMBOL	SAFETY DESCRIPTION			
	WEAR EYE PROTECTION			
	EAR PROTECTION MUST BE WORN			
	HARD HATS MUST BE WORN			
	PROTECTIVE GLOVES MUST BE WORN			
	PROTECTIVE FOOTWEAR MUST BE WORN			
A	OVERALLS MUST BE WORN			
	MACHINE GUARDS MUST BE USED			



2.2. Machine Hazards Signs

ISO 7010 SYMBOL	HAZARD DESCRIPTION
4	DANGER HIGH VOLTAGE
	WARNING MOVING MACHINERY
	CAUTION MOVING MACHINERY
	WARNING KEEP HANDS CLEAR

The Safety Alert Symbol appears throughout this manual. It is used to alert you to potential physical injury hazards. Pay close attention to Safety Alert Symbols and obey all safety messages that follow this symbol to avoid the possibility of death or serious injury.

Safety Alert Symbols are used in conjunction with certain Signal Words that call attention to safety messages or property damage messages and designate a degree or level of hazard seriousness. The Signal Words used in this manual are DANGER, WARNING, CAUTION.

DANGER Indicates a hazardous situation that, if not avoided, will result in death or serious personal injury.

WARNING Indicates a hazardous situation that, if not avoided, could result in death or serious personal injury.

<u>CAUTION</u> Indicates a hazardous situation that, if not avoided, could result in minor or moderate personal injury.

2.3. Safety Procedures

Detailed in this chapter is a list of good Health and Safety practices that Enerpac advise users to adhere to. Due to the nature of portable machine tools, not every eventuality can be catered for and the following is not exhaustive, as such Enerpac strongly advise that the user carries out their own

Doc: MML265

Issue: 004



risk assessments based on the machining and environment in which they intend to use the machinery.

2.3.1. Pre-Operational Safety Checks

- 1. Always read safety signs / labels
- 2. Ensure no slip / trip hazards are present in workspaces and walkways
- 3. Locate and ensure you are familiar with the operation of the ON / OFF starter and E-Stop (if fitted)
- 4. Do not leave equipment on top of the machine
- 5. Ensure each tool is in good condition and securely mounted
- 6. Secure / Remove loose items
- 7. Faulty equipment must not be used. Immediately report any suspect machinery

2.4. Operational Safety Checks

- 1. Operator is fully conversant and trained in use of equipment
- 2. Keep clear of moving machine parts
- 3. Never leave the machine running unattended
- 4. Follow correct clamping procedures keep overhangs as small as possible and check work piece is secure
- 5. Set the correct speed to suit the tool, the depth of cut and the material
- 6. Before making adjustments and measurements or before cleaning swarf accumulations switch off and bring the machine to a complete standstill

2.4.1. Housekeeping

- 1. Switch off the machine
- 2. Remove milling cutters, drill attachments and tap attachments and store them safely (if applicable)
- 3. Leave the machine and work area in a safe, clean and tidy state

2.4.2. Potential Hazards

- 1. Sharp cutters
- 2. Moving components hair / clothing entanglement
- 3. Eye injury
- 4. Skin irritation
- 5. Metal splinters and burrs
- 6. Flying debris

3. Handling

Customers, users and operators of the machines must be aware of the nature of the equipment supplied. Although inherently robust, the machine is a precision tool and may be damaged by poor handling, tipping and falling, inadequate transport arrangements over e.g. rough terrain, misuse by operators and use outside its design specification. Such poor handling may result in either broken or damaged parts or disturbance to fine settings resulting in an inability to meet the specified machining tolerances and capabilities.



4. Machine Specification

The Hot Tapping Machines have been modularly designed for accurate in-situ machining of work surfaces, to this end the constituent parts are easily manipulated by hand or crane.

Description	МНТ	MHT824-H		236-H	MHT1242-H		
Cutting Stroke	2032mm	80"	2794mm	110"	3352mm	132"	
Cutting Tool Diameters	203- 610mm	8-24"	305 – 914mm	12 – 36"	305 – 1067mm	12 – 42"	
Max Working Pressure	102bar	1480psi	102 bar	1480 psi	102 bar	1480 psi	
Max Operating Temperature (Continuous)	200°C	390°F	200°C	390°F	200°C	390°F	
Boring Bar Diameter	101.6mm	4"	101.6mm	4"	101.6mm	4"	
Cutter RPM Range	5-40	RPM	5-40 RPM		5-40 RPM		
Drive Motor Output (At 120 bar & 80L/min)	14 kW	19 Hp	14 kW	19 Hp	14 kW	19 Hp	
Hydraulic Supply Required (at 120bar)	80 L/min	21 G/min	80 L/min	21 G/min	80 L/min	21 G/min	
Auto Feed Rate (Single Speed)	0.076mm	0.003"	0.076mm	0.003"	0.076mm	0.003"	
Manual Feed Rate	8.5mm/rev	0.333"/rev	8.5mm/rev	0.333"/rev	8.5mm/rev	0.333"/rev	
Machine Weight	915 Kg	2017 Lbs	1371 Kg	3023 Lbs	1229 Kg	2709 Lbs	
Designed For General Use							



5. Installation

5.1. Fitting Cutters & Pilot Drills

Shown below is data relating to the cutters & pilot drills that are compatible with each 'Hot Tapping Machine'. Select the required cutter & pilot drill combination from the list below for your required application.

Cutter diameters increase in 2 inch (50.8mm) steps from 8 to 42 inches. Each cutter has a unique, corresponding pilot drill, the correct pilot drill MUST be used with its corresponding cutter. All these cutters & drills are available from Enerpac.

Cutters for the MHT824-H machine

MHT824-H Standard, Hot Tapping Cutter Data										
Cutter Adapters/ holder	Nominal Cutter Size		Actual Cutter Size		Standard Hot Tap Cutters			Standard Hot Tap Pilot Drills		
Part No	In	DN	In	ММ	Lbs	Kgs	Part No	Part No	Lbs	Kgs
	8	200	7.31	185.8	14.5	7	HTC8	SHTPD8	2	0.9
MHT824-56-001	10	250	9.5	241.3	22.5	10	HTC10	SHTPD10	2	0.9
	12	300	11.5	292	35	16	HTC12	SHTPD12	5	2.2
	12	300	11.5	292	35	16	HTC12	SHTPD12	5	2.2
	14	350	12.75	324	42	19	HTC14	SHTPD14	5.5	2.5
NAUT1242TD	16	400	14.69	373	55	25	HTC16	SHTPD16	6	2.7
MHT1242TD- 21-001	18	450	15.06	383	53	24	HTC18	SHTPD18	6	2.7
21-001	20	500	17	432	84	38	HTC20	SHTPD20	6.5	2.9
	22	550	19	483	99	45	HTC22	SHTPD22	7.5	3.4
	24	600	21	533	126	57	HTC24	SHTPD24	8	3.6

The MHT824-H comes with two different cutter adapters, the MHT1242TD-21-001 which is for cutter diameters of between 12 & 24 inches & the MHT824-56-001 for cutter diameters of 8 to 12 inches. Depending on which cutter is being used, select the appropriate cutter adapter (see table above).



Cutters for the MHT1236-H machine

MHT1236-H Standard, Hot Tapping Cutter Data										
Cutter Adapters/ holder	Nominal Cutter Size				Standard Hot Tap Cutters			Standard Hot Tap Pilot Drills		
Part No	In	DN	In	ММ	Lbs	Kgs	Part No	Part No	Lbs	Kgs
	12	300	11.5	292	35	16	HTC12	SHTPD12	5	2.2
	14	350	12.75	324	42	19	HTC14	SHTPD14	5.5	2.5
MHT1242TD-	16	400	14.69	373	55	25	HTC16	SHTPD16	6	2.7
21-001	18	450	15.06	383	53	24	HTC18	SHTPD18	6	2.7
	20	500	17	432	84	38	HTC20	SHTPD20	6.5	2.9
	22	550	19	483	99	45	HTC22	SHTPD22	7.5	3.4
	24	600	21	533	126	57	HTC24	SHTPD24	8	3.6
	26	650	23	584	135	61	HTC26	SHTPD26	8.5	3.8
MHT1242TD-	28	700	25	635	157	71	HTC28	SHTPD28	10.5	4.7
21-002	30	750	27	686	231	105	HTC30	SHTPD30	11	5
21-002	32	800	29	737	276	125	HTC32	SHTPD32	15	6.8
	34	850	31	787	331	150	HTC34	SHTPD34	15	6.8
	36	900	33	838	395	179	HTC36	SHTPD36	18	8.1

The MHT1236-H comes with two different cutter adapters, the MHT1242TD-21-002 for cutter diameters of between 24 & 36 inches or the MHT1242TD-21-002 for cutter diameters of between 12 & 22 inches. Depending on which cutter is being used, select the appropriate cutter adapter (see above).



Cutters for the MHT1242-H machine


MHT1242-H Standard, Hot Tapping Cutter Data										
Cutter Adapters/ holder	Nominal Cutter Size		Actual Cutter Size		Standa	ard Hot	Tap Cutters	Standard Hot Tap Pilot Drills		
Part No	In	DN	In	ММ	Lbs	Kgs	Part No	Part No	Lbs	Kgs
	12	300	11	292	35	16	HTC12	SHTPD12	5	2.2
	14	350	12	324	42	19	HTC14	SHTPD14	5.5	2.5
MHT1242TD-	16	400	14	373	55	25	HTC16	SHTPD16	6	2.7
21-001	18	450	15	383	53	24	HTC18	SHTPD18	6	2.7
21-001	20	500	17	432	84	38	HTC20	SHTPD20	6.5	2.9
	22	550	19	483	99	45	HTC22	SHTPD22	7.5	3.4
	24	600	21	533	126	57	HTC24	SHTPD24	8	3.6
	24	600	21	533	126	57	HTC24	SHTPD24	8	3.6
	26	660	23	584	187	85	HTC26	SHTPD26	8.5	3.8
	28	711	25	635	220	100	HTC28	SHTPD28	10.5	4.7
	30	762	27	685	238	108	HTC30	SHTPD30	11	5
MHT1242TD-	32	813	29	737	273	124	HTC32	SHTPD32	15	6.8
21-002	34	864	31	787	311	141	HTC34	SHTPD34	15	6.8
	36	914	33	838	346	157	HTC36	SHTPD36	18	8.1
	38	965	35	889	386	175	HTC38	SHTPD38	19	8.8
	40	1016	37	937	432	196	HTC40	SHTPD40	21	9.6
	42	1067	39	987	476	216	HTC42	SHTPD42	23	10.5

The MHT1242-H comes with two different cutter adapters, the MHT1242TD-21-001 which is for cutter diameters of between 12 to 24 inches & the MHT1242TD-21-002 for cutter diameters of 24 to 42 inches. Depending on which cutter is being used, select the appropriate cutter adapter (see table above).


Doc: MML265 Issue: 004 Issue Date: 13.06.2013



A 'cutter housing' or 'adapter flange' is fitted before the cutter itself. This acts as an adapter between the hot tapping machine & the 'Gate Valve' as well as housing the cutter assembly. Be sure to fit a new R.T.J sealing element between the 'cutter housing' & MHT Hot tapping Machine.



Extend the boring bar by positioning the feed handle in the backwards, neutral position & turning the 'Cranked Handle' anti-clockwise until it protrudes from the 'Cutter Housing', this will allow the cutter adapter to be fitted easily. Alternatively, use the fast traversal method to advance the boring bar (ref. Section 6)




Note: The 'Cutter Housing' is not shown in subsequent diagrams to allow them to be viewed easily.


Doc: MML265

Issue: 004



To install cutter adapter, align its slots to the Dog Ring on the boring bar, push adapter into tapered bore, tighten drawbar using the Measuring Rod from the back of the gearbox and then insert the boring bar retaining pin.





Note: The remaining instructions do not apply to the entire range of cutters & pilot drills, this example is for a 24" cutter.

Doc: MML265

Issue: 004




Installing the Cutter and pilot drill.

Align the six bolt holes in the cutter to the bolt holes in the pilot drill flange. Fit through 6 bolts as specified in the table below.

Align this cutter/ pilot drill assembly to the cutter adapter and then secure all 6 bolts through the plug adapter and fasten with nylon insert nuts.

If the pilot drill does not have a flanged end, the drill is directly screwed into the cutter adapter. The cutter should be secured to the cutter adapter using all six bolts.

Cutter adapter / holder number	Bolt size
MHT824-56-001	3/8-16 UNC
MHT1242TD-21-001	1/2-20 UNF
MHT1242TD-22-002	1/2-20 UNF




Doc: MML265 Issue: 004 Issue Date: 13.06.2013



5.2.Lifting

The MHT hot tapping machine is lifted & installed using a combination of four Lift Points mounted along the body of the machine as can be seen below.




If not already installed, fit the 'Rotating Lift Points' by screwing them into the machine body. Tighten the M16 lifting point bolts with a torque wrench to 320Nm (236 Lb/ft).


Doc: MML265

Issue: 004





If lifting the machine in a vertical arrangement, with the nose of the machine pointing downwards then only use the rearward mounted lifting points with suitable lifting equipment i.e. overhead crane as shown above.



If lifting the machine in a horizontal arrangement the two lifting points along the body of the machine should be used along with suitable lifting equipment i.e. overhead crane as shown above.

Doc: MML265

Issue: 004



5.3. Securing to pipeline.

The hot tapping machine is mounted to a live pipeline via a pre-installed 'Gate Valve'. It is secured by a series of twelve high tensile 1" studs & nuts to the cutter housing or 'Adapter Flange'. The 'Adapter Flange' is then secured to the 'Gate Valve' by a similar series of bolts or studs.

Before making any attempt to secure the hot tapping machine to a 'Gate Valve', measurements should be taken to predict how far the cutter should be fed until it has completely cut through one side of the pipe wall. Use the 'Hot Tapping Data Sheet' in the back of this manual to record such measurements.

- 1. Retract the cutter into the 'Cutter Housing' to prevent it clashing with any of the pipeline assembly whilst lifting the hot tapping machine into place.
- 2. Fit a new sealing element between the 'Cutter Housing' & the 'Gate Valve'.
- 3. Safely lift & manoeuvre the MHT hot tapping machine until the 'Cutter Housing' is roughly aligned with the 'Gate Valve'.
- 4. Ensure that before securing the MHT to the pipeline, it is orientated such that the gearbox controls will be easily accessible when the machine is in place.
- 5. Align the corresponding holes between the 'Cutter Housing' & 'Gate Valve', insert appropriate studs & nuts & tighten equally using a calibrated torque wrench to the correct torque figure.
- 6. To make sure the cutter has not been trapped, rotate the 'Cranked Handle' to check the cutter can move freely up & down the cutter housing.
- 7. The MHT is now properly installed & the Motor hoses can now be connected.

5.4. Service and Supplies

The OMT500 hydraulic motor fitted to the MHT machines requires a flow rate of 80 litres per minute at 120 bar of pressure (21 gallons per minute at 1740 psi) to operate correctly.

5.4.1. Personnel

As a specialist portable machine the minimum standard for an operator is to be:


- The operator must be trained and conversant with the Enerpac MHT machines.
- The operator to be able to identify the correct and incorrect use of static or portable machines
- Comply with all local and internationally recognised safe use of powered machines




6. Machine Operation



Note: Before turning the hydraulic motor on ensure the 'Crank Handle' is removed or the gear lever is in the neutral position otherwise this will rotate when the motor is turned on.



- 1. To position the cutter & pilot drill assembly prior to cutting, turn the 'Crank Handle' anti-clockwise with the gear lever pushed backwards, the motor turned off & the 'Gate Valve' open until the pilot drill stops when it hits the pipe. Turn the 'Crank Handle' the opposite direction for half a turn to allow a gap between the pilot drill & pipe.
- 2. Ensure the cutter does not feed forwards when the hydraulic motor is turned on by positioning the gear lever in the neutral position. Also, **remove the crank handle before engaging the hydraulic motor.**




Doc: MML265

Issue: 004



3. Start the cutter rotation by engaging the hydraulic motor, the cutter will now be rotating but not feeding towards the pipe.


The cutter speed and direction can be monitored by using the viewing window located in the machine cylinder. A white mark will be painted on the inner tubing to assess the speed by counting the revolutions per minute. Alternatively mark the measuring rod and this can be used to assess the speed and cutter direction.



- 4. Note where the measuring rod is sitting at the back of the gearbox, this is marked at 25.4mm (1") increments, use these along with pre-cut data that should have been recorded on the 'Hot Tapping Data Sheet' at the back of this manual as a guide for how far the cutter needs to be advanced.
- 5. To start feeding the cutter towards the pipe, push the gear lever forwards (towards the cutter end of the machine). The hydraulic motor can be slowed momentarily to make the gear selection easier, return motor to operational speed afterwards.
- 6. Using the 'Measuring Rod' & pre-cut data which should have been recorded on the 'Hot Tapping Data Sheet' at the back of this manual, continue to feed the cutter into the pipeline until it has made a complete cut through one side of the pipe.
- 7. Stop the cutter from feeding by returning the gear lever to the neutral position & turn the hydraulic motor off.
- 8. Retract the cutter by turning the 'Cranked Handle'. The pipeline 'coupon' will be retained by the pilot drill, this can be recovered later when the machine is removed from the pipeline.



9. To quickly return the assembly, engage the fast traverse. This is achieved by pulling the locking lever at the back of the gearbox upwards to lock off the feed handle in neutral, and then pushing the fast traverse handle forwards. It may be necessary to power the motor at low speeds to engage the gears. Ensure that the cutter is not spinning during fast traverse by hydraulically locking the feed motor. Note that the hydraulic controls for the drive motor have grub screws which prevent the use of the drive motor to reverse the cutter out – this is to stop the cutter tips from being stripped from the cutter.






7. Completion Plug Installation Guidance


The hot tapping machine can be used to install a completion plug which is used to seal the opening branch in the pipeline used by the cutting operation of the hot tapping machine.

To install the plug to the hot tapping machine, the cutter and adapter must first be removed.

The Cutter and pilot drill is removed from the cutter adapter by unscrewing the bolts and Nyloc nuts.



The cutter adapter should then be detached by removing the boring bar pin and then unscrewing the cutter adapter from the drawbar. The dog ring should also be removed.




Doc: MML265


Issue: 004



Fit the required size flange adapter to the spool end. The plug adapter can now be installed. Use the measuring rod to rotate the drawbar into the plug adapter. Do not overtighten.



To ensure that the cylinder does not rotate when traversing the plug to position, lock 6 x M20 bolts. There are 2 banks of 3x M20 bolts. Each should be tightened by loosening the locknut, then tightening the bolt to the cylinder, and finally re-tightening the lock nut.




Doc: MML265

Issue: 004




Fit the completion plug to the plug adapter, and securely remount machine to the gate valve.



If available, the fast traverse can be used to position the plug into the gate valve branch for 95% of the distance – refer to section 6, machine operation – on guidance of using the fast traverse.

For the final 5%, use the 'Crank Handle', turning it anti-clockwise with the gear lever pushed in the neutral position and the motor turned off.




Doc: MML265


Issue: 004



When the plug is in position, secure the completion plug as required.



Once the plug is secured satisfactorily, the plug and plug adapter are separated from the hot tapping machine by using the measuring bar to unscrew the drawbar from the plug adapter. Continue to rotate the measuring bar until the plug is detached.



Once the drawbar has been detached from the plug holder, begin retracting the boring bar using the crank handle. Withdraw the first 50mm using the crank handle. Once past this point, the fast traverse motor can be used if supplied.


Doc: MML265

Issue: 004



When the boring bar is retracted and the completion plug is safely secured, the hot tapping machine can be removed from the gate valve.

The plug adapter should be removed from the plug before securing a suitable blind flange.





8. Machine Maintenance

General wear and tear items should be replaced with like for like components as per the machine general assembly drawings detailed in this manual. Failure to do so may result in a machine that is not fit for purpose and is outside the design intent it was supplied for. Items that require specific maintenance regimes and products will be detailed here in.

	General Maintenance Schedule							
Time Period	Action	Recommended Lubricant						
After every use	Clean all cutting debris from machine. Pay particular attention to lead screws, pivots, sealing, sliding & rotating faces.	General water displacing, cleaning oil.						
As required	Replace cutting tool/cutting tool inserts.	N/A						
Every 10 hours	Apply a small amount of low viscosity oil to all lead screws, pivots, sliding & rotating faces.	Mineral based SAE 10 oil.						
	Check all securing nuts & bolts are tight.	N/A						
Every 100 hours	Check for backlash in lead screw/lead screw nut & correct if necessary.	N/A						
Before long term storage (12 months minimum)	Protect machine, components & accessories from corrosion. Store all machine components securely in original packing box.	General, oil based, rust inhibitor.						

8.1. Maintenance

- To ensure that the machine is lubricated, either apply grease through the grease point on the machine spool, or extend the boring bar completely and apply oil to the bar.
- Check the tightness of the seal cartridge located in the spool and the locking nut within the driveshaft end.
- Remove the inspection cover on the main cylinder and check the keys. Wind the driveshaft assembly out of the way to access the leadscrew and apply grease to it.
- The machine seals must be pressure tested before every use of the machine.
- Pay close attention to the full thread length of the feedscrew, check for signs of wear or damage


Doc: MML265 Issue: 004 Issue Date: 13.06.2013




8.2. Seal Replacement Procedure

8.2.1. Replacing the spool seal

The MHT824-H, MHT1236-H and MHT1242-H all utilize the MHT1242-1 drive gearbox assembly in which the seal is contained.



1. Before removing the spool from the drive gearbox, ensure that the cutter holder and dog ring have been removed from the driveshaft.




- 2. Then slightly loosen the seal cartridge using a face spanner (p/n 95350.W0201). Note that this is a left-hand thread.
- 3. Unbolt the spool assembly from the drive gearbox, and carefully remove the spool from the drive shaft.

Doc: MML265


Issue: 004



- 4. Fully unscrew the seal cartridge and remove it from the spool.
- 5. Remove the spacers and compression spring.
- 6. Remove the existing chevron seal.




- 7. As the new seal is positioned in the spool, oil the individual components and ensure the chevrons are facing the same direction as shown on the machine general assembly drawing.
- 8. Replace wiper seal within the seal cartridge (SWAN2204000-FLN2V).
- 9. Then replace the remaining components as shown above.
- 10. Ensure the drive shaft is clean and debris free before re-fitting the spool onto it. Take care not to damage the surface of the seal.
- 11. Connect the spool to the drive gearbox using the M16 bolts.






8.2.2. Replacing the drawbar seal

The drawbar seal can be found in the drive shaft as shown below.



- 1. Remove the locking nut (MHT1242-5A-003) from within the driveshaft taper using the extraction tool (MMT-1-006). Note this is a left hand thread.
- 2. When the locking nut is removed, push the drawbar forward to release the seal assembly and remove the existing chevron seal package.




Doc: MML265

Issue: 004



3. Oil the individual components as they are fitted and ensure that the chevrons are facing the same way as shown below.



- 4. Retract the drawbar back into the drive shaft.
- 5. Ensure the seals are fully pushed into the bore by using the chevron seal setting tube (MHT1242TD-TK-001).
- 6. Refit and fully tighten the locking nut.

Doc: MML265 Issue: 004 Issue Date: 13.06.2013



9. Troubleshooting Guide

Symptom	Possible cause	Action
	Hydraulic/Pneumatic supply not available	Check supply
	2. Hydraulic/Pneumatic supply is below the minimum required to operate the machine	Check supply
The machine will not rotate	3. Drive motor faulty	Remove motor and check operation
	4. Damage to drive gear train	Remove motor and check free rotation
	5. Faulty valve or emergency shut off operational	Check supply to motor
	1. The feed control valve is not correctly set	Check position
The machine does not traverse	2. Drive gear problem	Remove and check drive assembly operation
	3. Depth of cut too deep	Remove cut and check rotation

In the event that the cutter has become stuck and the instructions in the machine operation section have not solved the issue;

The hydraulic controls for the drive motor have grub screws which prevent the use of the drive motor to reverse the cutter out — this is to stop the cutter tips from being stripped from the cutter. If all other methods have been exhausted, then adjust those grub screws to allow the drive motor to reverse the cutter out. This will almost certainly damage the cutter, so it must only be considered as a last resort.




10. General Assembly Drawings

The table below can be used as a quick reference to the drawings provided in this section.

Drawing name	MHT824-H drawing Numbers	MHT1236-H drawing Numbers	MHT1242-H drawing Numbers
General assembly drawing	MHT824-H	MHT1236-H	MHT1242-H
Drive gearbox assembly*	MHT1242-1	MHT1242-1	MHT1242-1
Drive shaft	MHT824-50	MHT1236-50	MHT1242TD-2
Drawbar assembly	MHT824-51	MHT1236-51	MHT1242TD-5A
Lifting bracket	MHT1242-11	MHT1242-11	MHT1242-11
Drive tube assembly	MHT824-52	MHT1236-52	MHT1242-13
Leadscrew assembly	MHT824-53	MHT1236-53	MHT1242-14
Gearbox assembly	MHT1242-19	MHT1242-19	MHT1242-19
Cutter holder set	MHT824-56	MHT1242TD-21	MHT1242TD-21
Plug holder set	MHT824-57	MHT1242TD-20	MHT1242TD-20
Tool kit	MHT1242-H-TK	MHT1242-H-TK	MHT1242-H-TK
Spares kit	MHT824-H-SK	MHT1236-H-SK	MHT1242-H-SK
Hydraulic control panel	MHT824-HDCP-CM	MHT1236-HDCP-CM	MHT1242-HDCP-CM


^{*} For alternative gearbox assembly (part number MHT1242-34) refer to appendix 11.5

ENERPAC. 2




Doc: MML265 Issue: 004 Issue Date: 13.06.2013


ENERPAC. 2





ENERPAC. 2





ENERPAC. 🛭






















ENERPAC. 🕝















Doc: MML265 Issue: 004 Issue Date: 13.06.2013




Enerpac · 8-10 Enterprise Way · Derby · DE21 4BB · UK · t: +44 (0)1332 291767












155de 155de





ENERPAC. 🕝





ENERPAC. 🕝













Enerpac · 8-10 Enterprise Way · Derby · DE21 4BB · UK · t: +44 (0)1332 291767


Page **59** of **89**





Enerpac · 8-10 Enterprise Way · Derby · DE21 4BB · UK · t: +44 (0)1332 291767

Page **60** of **89**










Enerpac · 8-10 Enterprise Way · Derby · DE21 4BB · UK · t: +44 (0)1332 291767





Printed on 29/01/2020 DO NOT SCALE IF IN DOUBT ASK

PART NO.	DESCRIPTION	QTY.
2204000-FLN2V	WIPER SEAL WITH ORING	1
KK12-8-60A	TYPE A KEY	1
MHT1242-1-008	COMPRESSION SPRING	1
CHEVRON-SEAL- STACK-25.4-4	CHEVRON SEAL STACK 25.4-40.7-23.5mm	1
14.90x2.5x1M	PISTON WEAR BAND	2
3304-2RS	BEARING	1
6208-2RS	RADIAL BEARING	4
61926	DEEP GROOVE BALL BEARING	3
MHT824-2-010	TUFNOL CAP	2
CH044517-200- CHEVRON	CHEVRON SEAL 200 DEGREES C	1
R45-RTJ-SEAL	RING JOINT R45 OVAL SOFT IRON ASME B16.20	1
MHT1242-2-006	DRIVE KEY	2
51228	THRUST BALL BEARING SINGLE DIRECTION	1
51122	THRUST BALL BEARING SINGLE DIRECTION	1
32934	TAPER ROLLER BEARING SINGLE ROW	1
29317E	SPHERICAL ROLLER THRUST BEARING	1
61818-2RS1	DEEP GROOVE BALL BEARING	1
6012-2RS1	RADIAL BEARING	1
KK8-7-32A	TYPE A KEY	2
3205A-2RS1	DOUBLE ROW BALL BEARING	6
6328-RS	SEALED BEARING	1
NX20-ZXL	NEEDLE ROLLER BEARING	1
KK14-9-40A	TYPE A KEY	2

D	-	Updated BoM as new machine version in development			29/01/2020	DRB		RH
С	-	Updated BoM to reflect current machine			28/01/2020			RH
REV.	INC.	DESCRIPTION			DATE	DRAWN BY	APP	ROVED
NO	THIRD ANGLE PROJECTION O MIRAGE MACHINES LTD ALL RIGHT'S RESERVED UNDER COPYRIGHT, DESIGN AND PATENT LAW. NO COPY OF THIS DOCUMENT OR THE ARTICLE SHOWN MAY BE MADE WITHOUT PRIOR WRITHEN PERMISSION THIRD ANGLE PROJECTION O MIRAGE MACHINES LTD AND PATENT LAW. NO COPY OF THIS DOCUMENT OR THE ARTICLE SHOWN MAY BE MADE WITHOUT PRIOR WRITHEN PERMISSION							
	IGHT	Kg		10 ENTERPE	RISE WAY, JU	JBILEE PA	ARKV	VAY,
	WN BY	DB	11/06/2015	STORES	S ROAD, DEF	RBY DE21	4BB	
CHEC	KED B	f BC	11/06/2015				32) 370356	
APPRO	OVED B	Υ	-	E MAIL i	nfo@mirage-r	machines.	.co.uk	
Spares Kit MHT824-H-SK							A4	
		SUALE. I.I		0	HEET LOF I			

MIRAGE MACHINES

APPROVED FOR
MANUFACTURE

N:\Drawing Storage\DRAWINGS\MHT824-H-SK

Doc: MML265 Issue: 004 Issue Date: 13.06.2013



DO NOT SCALE IF IN DOUBT ASK Printed on 29/01/2020

PART NO.	DESCRIPTION	QTY.
2204000-FLN2V	WIPER SEAL WITH ORING	1
KK12-8-60A	TYPE A KEY	1
MHT1242-1-008	COMPRESSION SPRING	1
CHEVRON-SEAL- STACK-25.4-4	CHEVRON SEAL STACK 25.4-40.7-23.5mm	1
14.90x2.5x1M	PISTON WEAR BAND	2
3304-2RS	BEARING	1
6208-2RS	RADIAL BEARING	4
61926	DEEP GROOVE BALL BEARING	3
MHT824-2-010	TUFNOL CAP	2
CH044517-200- CHEVRON	CHEVRON SEAL 200 DEGREES C	1
R45-RTJ-SEAL	RING JOINT R45 OVAL SOFT IRON ASME B16.20	1
MHT1242-2-006	DRIVE KEY	2
51228	THRUST BALL BEARING SINGLE DIRECTION	1
51122	THRUST BALL BEARING SINGLE DIRECTION	1
32934	TAPER ROLLER BEARING SINGLE ROW	1
29317E	SPHERICAL ROLLER THRUST BEARING	1
61818-2RS1	DEEP GROOVE BALL BEARING	1
6012-2RS1	RADIAL BEARING	1
KK8-7-32A	TYPE A KEY	2
3205A-2RS1	DOUBLE ROW BALL BEARING	6
6328-RS	SEALED BEARING	1
NX20-ZXL	NEEDLE ROLLER BEARING	1
KK14-9-40A	TYPE A KEY	2

С	-	development			29/01/2020	DRB	RH
В	-	Updated BoM to match current machine design			28/01/2020	DRB	RH
REV.	INC.	DESCRIPTION			DATE	DRAWN BY	APPROVED
NO	COPY	THIRD ANGLE MIRAGE MACHINES LTD TS RESERVED UNDER COPYRIGH AND PATENT LAW. FINIS DOCUMENT OR THE ARTI ADE WITHOUT PRIOR WRITTEN PE		R			
	IGHT	Kg		10 ENTERPR			
DRA	DRAWN BY DB 11/06/2015				S ROAD, DEF		
CHEC	CHECKED BY BC 11/06/2015			TEL (01332)			
	OVED B	Y		nfo@mirage-r	nachines.	.co.uk	
TITLE		Spares Kit	DWG No MHT	1236 - H	-SK	A4	

MIRAGE MACHINES APPROVED FOR MANUFACTURE

N:\Drawing Storage\DRAWINGS\MHT1236-H-SK

Doc: MML265 Issue: 004 Issue Date: 13.06.2013

SCALE: 1:1

A4

SHEET 1 OF 1



Printed on 21/08/2019 DO NOT SCALE IF IN DOUBT ASK

PART NO.	DESCRIPTION	QTY.
MHT824-2-010	TUFNOL CAP	1
14.90X2.5x1M	14.9mm x 2.5mm x 1m LENGTH B/F (F01) ECOFLON 3 WEARBAND	1
KK12-8-60A	FEATHER KEY: 12MM w X 8MM H X 60MM LG KEY 2 ROUND ENDS TYPE A	1
R45-RTJ-SEAL	RING JOINT R45 OVAL, SOFT IRON ASME B16.20	1
SWAN2204000-FLN2V	Seal with O-Ring	1
CH044517-SWAN-200DEG-CHEVRON	CHEVRON SEAL	1
CHEVRON-SEAL-STACK-25.4-4	CHEVRON SEAL STACK 25.4-40.7-23.5mm VITON / PTFE (200DegC)	1
MHT1242-1-005	BUSH	1
14x9x40	TYPE A KEY	1
61926	BEARING	2
51228D1	BEARING	4
32934D1	BEARING	2
29317ED1	BEARING	4
51122D1	BEARING	1

MIRAGE MACHINES

APPROVED FOR
MANUFACTURE

N:\Drawing Storage\DRAWINGS\MHT1242-H-SK





Printed on 23/11/2018	D	OO NOT SCALE IF IN DOUBT ASK	
	PART NO.	DESCRIPTION	QTY
	KEN-602-5500K	BALL DRIVER "L" WRENCHES	1
^	KEN-601-5170K	17mm ALLEN KEY LONG ARM	1
B	KEN-601-5140K	14mm ALLEN KEY LONG ARM	1
	KEN-582-2891K	55mm COMBI SPANNER	1
	KEN-582-2880K	46mm COMBI SPANNER	1
B	KEN-5822840K	36mm COMBI SPANNER	1
<u> </u>	KEN-582-2820K	30mm COMBI SPANNER	1
	MMT-54	WELDED DRIVE BAR	1
	KEN-582-7010K	19mm SOCKET 1/2" SQ. DRIVE	1
	TOOLBOX-706-4701	TOOLBOX STANLEY FATMAX 1-95-615	1
	SELLOC8x45	8 x 45 SELLOC PIN	10
	MMT-1-006	EXTRACTION TOOL	1
	MHT312-12-015	SMALL HANDLE	1
c	KZ011922	GEDORE 3293 U-3 REVERSABLE RATCHET 3/4 DR 620MM OAL	1
	ISM25X3/4	LJ01 25MMX3/4SD IMPACT SOCKET	1
	MHT1242-TK-001	CHEVRON SETTING TOOL	1
	95350.W0125	FACE SPANNER	1

MIRAGE MACHINES


APPROVED FOR

MANUFACTURE

С	-	Added reversable ratchet, fac spanner, setting tool and impa- socket		23/11/2018	DRB	RBA
В	-	Added 17mm allen key and 30mm spanner		16/11/2018	DRB	DMS
REV.	INC.	DESCRIPTION		DATE	DRAWN BY	APPROVED
						~ 1 =
NO CO MAY E	PY OF THE BE MADE	MIRAGE MACHINES LTD ESERVED UNDER COPYRIGH AND PATENT LAW. AND PATENT LAW. IS DOCUMENT OR THE ARTI WITHOUT PRIOR WRITTEN P	CLE SHOWN ERMISSION		BLE PERFO	RMANCE
NO CO	RIGHTS R PY OF TH BE MADE HT	ESERVED UNDER COPYRIGH AND PATENT LAW. 4IS DOCUMENT OR THE ARTI WITHOUT PRIOR WRITTEN P	CLE SHOWN ERMISSION	PORTA 0 ENTERPRISE WA	BLE PERFO	RMANCE PARKWAY.
NO CO MAY E	RIGHTS R PY OF TH BE MADE HT I BY	ESERVED UNDER COPYRIGH AND PATENT LAW. HIS DOCUMENT OR THE ARTI WITHOUT PRIOR WRITTEN P	CLE SHOWN ERMISSION 10 08/11/2018	PORTA 0 ENTERPRISE WAS STORES ROAD	BLE PERFO	PARKWAY, 1 4BB
NO CO MAY E WEIGH DRAWN	RIGHTS R PY OF TH BE MADE HT I BY	ESERVED UNDER COPYRIGH AND PATENT LAW. IIS DOCUMENT OR THE ARTI WITHOUT PRIOR WRITTEN P Kg DRB	CLE SHOWN ERMISSION 10 08/11/2018	PORTA 0 ENTERPRISE WA	AY, JUBILEE F DERBY DE2 FAX (0133	PARKWAY, 1 4BB 12) 370356

Doc: MML265 Issue: 004 Issue Date: 13.06.2013


N:\Drawing Storage\DRAWINGS\MHT1242-H-TK



NO.	PART NUMBER	DESCRIPTION	QT
1	19990	BOTTOM CLAMP	-4
2	19991	PIPE CLAMP BRACKET	1
3	19992	BULKHEAD BRACKET	1
4	19993	MHT824 PVG HOUSING	1
5	19994	FLOW CONTROL VALVE BRACKET	1
6	A2028VB01	PVG32 CONTROL VALVE	1
7	V1080	FLOW CONTROL VALVE - VPR3 3/4"	1
8	5100-52-168	1" 5100 SERIES MALE PROBE	1
9	5100-52-208	1-1/4" 5100 SERIES MALE PROBE	1
10	SPG-063-00160-01-P-804-U	PRESSURE GAUGE	1
11	SP-426.9/26.9-PPH-GD-AS-M-W10	GP.4 TWIN PIPE CLAMP	1
12	SP 535/35-PPH-GD-AS-M-W10	GP.5 TWIN PIPE CLAMP	1
13	FI-RSW-10LR-WD-B-W3	BANJO ELBOW (WD TYPE) BODY ONLY	1
14	FI-GE-12LR1/2-WD-B-W3-MS	MALE STUD COUPLING WD TYPE (BODY ONLY)	- 4
15	FI-GE-18LR3/4-WD-B-W3	MALE STUD COUPLING (BODY ONLY) WD TYPE	1
16	FI-EWD-18L-B-W3-DKO	ADJUSTABLE ELBOW (BODY ONLY)	-1
17	FI-GE-22LR1/2-WD-B-W3	MALE STUD COUPLING WD TYPE (BODY ONLY)	2
18	FI-GE-22LR-WD-B-W3	MALE STUD COUPLING BSP (WD TYPE) BODY ONLY	3
19	FI-EGED-22LR-WD-8-W3-DKO	STRAIGT MALE STUD CONNECTOR	-1
20	FI-EWD-22L-8-W3-DKO	ADJUSTABLE ELBOW (BODY ONLY)	1
21	FI-W-22L-W3	TUBE ELBOW (BODY ONLY)	-1
22	FI-GS-28L-W3-SKM	STRAIGHT BULKHEAD FITTING (BODY + LOCKNUT ONLY)	1
23	FI-EVD-28L-B-W3-DKO	ADJUSTABLE ELBOW 45 (BODY ONLY)	-1
24	FI-T-28/18/28L-W3	UNEQUAL TUBE TEE (BODY ONLY)	1
25	FI-GE-28LR3/4-WD-8-W3	MALE STUD COUPLING WD TYPE (BODY ONLY)	2
26	FIEGED-28L1N-8-W3-DKO	STUD STANPIPE (NPT)	1
27	FI-REDSD-35/28L-8-W3-DKO	STRAIGHT REDUCER (BODY ONLY)	1
28	FI-GS-35L-W3-SKM	STRAIGHT BULKHEAD FITTING (BODY ONLY)	1
29	FI-EVD-35L-B-W3-DKO	ADJUSTABLE ELBOW (45) BODY ONLY	-1
30	FFEGED-35L1-1/4N-8-W3-DKO	STUD STANDPIPE (NPT)	1 2
31	1/2" BSP X 1/2" BSP M/F FIXED	FIXED STRAIGHT BUSH	
32	\$6-PP-45-D	1-2" BONDED WASHER	2
33	ADP-C-G12-MFX-W66A	FIXED STRAIGHT BUSH	2
34	\$6-PP-45-F	3-4" BONDED WASHER	2
35	20099-H01	3/4" 25SK 22L 90 22L STR 1240mm LONG	1
36	20099-H02	3/4" 2SSK 22L 90 22L STR 1455mm LONG	1
37	20099-H03	1" 25SK 28L STR 28L STR 1465mm LONG	1
38	20099-H04	1" 2SSK 28L STR 28L STR 1240mm LOING	- 1
39	20099-H05	3/8" 255K 12L 90 12L 90 BOTH 0 DEGREES 875mm LONG	1
40	20099-H06	3/8" 255K 12L 90 12L 90 BOTH 0 DEGREES 950mm LONG	
41	20099-H07	SMS-K10L/M1/4-CU-300-B-W3	- 1
42	20099-P01	28x2 C6F 180mm LONG	-1
43	20099-P02	22x2 C6F 107.66mm LONG	1
44	20099-P03	18x1.5 C6F 211.55mm LONG	1

NOTES:

- FRAME + CLAMPS PAINTED TO RAL 9005.
 HYDRAULIC KIT FOR MHT824-H.




Doc: MML265


Issue: 004

Issue Date: 13.06.2013

ENERPAC. &




Enerpac · 8-10 Enterprise Way · Derby · DE21 4BB · UK · t: +44 (0)1332 291767




TEM NO.	PART NUMBER	DESCRIPTION	QTY.
IEM NO.	19990	BOTTOM CLAMP	5
2	19991	PIPE CLAMP BRACKET	2
3	19992	BULKHEAD BRACKET	1
4	19993	PVG BASE FRAME	-
5	19994	FLOW CONTROL VALVE BRACKET	i
6	A 2028VB01	PVG32 CONTROL VALVE	1
7	V1080	FLOW CONTROL VALVE - VPR3 3/4"	- 1
8	5100-52-168	1" 5100 SERIES MALE PROBE	- 1
9	5100-52-208	1-1/4" 5100 SERIES MALE PROBE	- 1
10	SPG-063-00160-01-P- B04-U	PRESSURE GAUGE	- 1
- 11	SP-426.9/26.9-PPH-GD- AS-M-W10	GP.4 TWIN PIPE CLAMP	2
12	SP 535/35-PPH-GD-AS- M-W10	GP.5 TWIN PIPE CLAMP	2
13	FI-RSW-10LR-WD-B-W3	BANJO ELBOW (WD TYPE) BODY ONLY	- 1
14	FI-GE-12LR1/2-WD-8- W3-MS	MALE STUD COUPLING WID TYPE (BODY ONLY)	4
15	FI-GE-18LR3/4-WD-8- W3	MALE STUD COUPLING (BODY ONLY) WD TYPE	- 1
16	FI-EWD-18L-B-W3-DKO	ADJUSTABLE ELBOW (BODY ONLY)	- 1
17	FI-GE-22LR1/2-WD-8- W3	MALE STUD COUPLING WD TYPE (BODY ONLY)	2
18	FI-GE-22LR-WD-B-W3	MALE STUD COUPLING BSP (WD TYPE) BODY ONLY	3
19	FI-EGED-22LR-WD-8- W3-DKO	STRAIGT MALE STUD CONNECTOR	- 1
20	FI-EWD-22L-8-W3-DKO	ADJUSTABLE ELBOW (BODY ONLY)	- 1
21	FI-W-22L-W3	TUBE ELBOW (BODY ONLY)	1
22	FI-GS-28L-W3-SKM	STRAIGHT BULKHEAD FITTING (BODY + LOCKNUT ONLY)	1
23	FI-EVD-28L-8-W3-DKO	ADJUSTABLE ELBOW 45 (BODY ONLY)	
24	FI-T-28/18/28L-W3	UNEQUAL TUBE TEE (BODY ONLY)	- 1
25	FI-GE-28LR3/4-WD-8- W3	MALE STUD COUPLING WD TYPE (BODY ONLY)	2
26	FI-EGED-28L1N-B-W3- DKO	/3- STUD STANPIPE (NPT)	
27	FI-REDSD-35/28L-8-W3- DKO	STRAIGHT REDUCER (BODY ONLY)	- 1
28	FI-GS-35L-W3-5KM	STRAIGHT BULKHEAD FITTING (BODY ONLY)	1
29	FI-EVD-35L-8-W3-DKO	ADJUSTABLE ELBOW (45) BODY ONLY	- 1
30	FI-EGED-35L1-1/4N-B- W3-DKO	STUD STANDPIPE (NPT)	- 1
31	1/2" BSP X 1/2" BSP M/F FIXED	FIXED STRAIGHT BUSH	2
32	S6-PP-45-D	1-2" BONDED WASHER	2
33	20100-H01	3/4" 2SSK 22L 90 22L STR 1965mm LONG	1
34	20100-H02	3/4" 2\$\$K 22L 90 22L \$TR 2175mm LONG	- 1
35	20100-H03	1" 255K 28L STR 28L STR 1930mm LONG	1
36	20100-H04	1" 255K 28L STR 28L STR 2215mm LONG	- 1
37	20100-H05	3/8" 2SSK 12L 90 12L 90 BOTH 0 DEGREES 990mm LONG	- 1
38	20100-H06	3/8" 2SSK 12L 90 12L 90 BOTH 0 DEGREES 930mm LONG	- 1
39	20100-H07	SMS-K10L/M1/4-CU-300-B-W3	- 1
40	20100-P01	28x2 C6F 180mm LONG	1
41	20100-P02	22x2 C6F 107.66mm LONG	- 1
42	20100-P03	18x1.5 C6F 211.55mm LONG	- 1


- NOTES:
 FRAME + CLAMPS PAINTED TO RAL 9005.
- . HYDRAULIC KIT FOR MHT1236-H.




Doc: MML265 Issue: 004


ENERPAC. &





TEM NO.	PART NUMBER	DESCRIPTION	
1	19983 (1)	PVG FRAME	- 1
2	19983 (2)	CLAMP	- 3
	19983 (3)	CLAMP (2)	(
4	19983 (4)	BRACKET (3)	1
5	19994	FLOW CONTROL VALVE BRACKET	1
6	A1726VB01	AUX FEED PVG VALVE	1
7	11186714	OMP 400	
	15183005	OMT 500	ш
9	V1080	FLOW CONTROL VALVE - VPR3 1/2"	
	801300005	A9 3-8" BSP QRC	
	801300006	A9 3-8" BSP QRC	
	801300007	A9 1-2" BSP QRC	ш
	801300008	A9 1-2" BSP QRC	L
14	801300040	F.A.17.3/4" BSP	
	801300041	A17 3/4 BSP QRC	L
16	5100-S2-16B	1" 5100 SERIES MALE PROBE	L
17	5100-S2-20B	1-1/4" 5100 SERIES MALE PROBE	L
	SPG-063-00160-01-P-804-U	PRESSURE GAUGE	╙
19	SP-426.9/26.9-PPH-GD-AS-M-W10	GP.4 TWIN PPE CLAMP	
20	SP 535/35-PPH-GD-AS-M-W10	GP.5 TWIN PIPE CLAMP	
21	FI-RSW-10LR-WD-B-W3	BANJO ELBOW (WD TYPE) BODY ONLY	
22	FI-GE-12LR-WD-B-W3	MALE STUD COUPLING WD TYPE (BODY ONLY)	
	FI-GE-12LR1/2-WD-B-W3-MS	MALE STUD COUPLING WD TYPE (BODY ONLY)	
24	FI-GE-18LR-WD-B-W3	MALE STUD COUPLING (WD TYPE) BOSY ONLY	
25	FI-EWD-18L-B-W3-DKO	ADJUSTABLE ELBOW (BODY ONLY)	
26	FI-GE-22LR1/2-WD-B-W3	MALE STUD COUPLING WD TYPE (BODY ONLY)	
27	FI-GE-22LR-WD-B-W3	MALE STUD COUPLING BSP (WD TYPE) BODY ONLY	
	FI-EGED-22LR-WD-B-W3-DKO	STRAIGT MALE STUD CONNECTOR	
29	FI-EWD-22L-B-W3-DKO	ADJUSTABLE ELBOW (BODY ONLY)	Г
30	FI-W-22L-W3	TUBE ELBOW (BODY ONLY)	
31	FI-GS-28L-W3-SKM	STRAIGHT BULKHEAD FITTING (BODY + LOCKNUT ONLY)	П
32	FI-EVD-28L-8-W3-DKO	ADJUSTABLE ELBOW 45 (BODY ONLY)	П
33	FI-T-28/18/28L-W3	UNEQUAL TUBE TEE (BODY ONLY)	
34	FI-GE-28LR3/4-WD-B-W3	MALE STUD COUPLING WD TYPE (BODY ONLY)	
35	FI-EGED-28L1N-8-W3-DKO	STUD STANPIPE (NPT)	Г
36	FI-REDSD-35/28L-B-W3-DKO	STRAIGHT REDUCER (BODY ONLY)	Г
37	FI-GS-35L-W3-SKM	STRAIGHT BULKHEAD FITTING (BODY ONLY)	Г
38	FI-EVD-35L-B-W3-DKO	ADJUSTABLE ELBOW (45) BODY ONLY	
39	FI-EGED-35L1-1/4N-B-W3-DKO	STUD STANDPIPE (NPT)	
40	ADP-C-G08-MM-W66A	1/2" BSP X 1/2" BSP MALE/MALE	
41	ADP-C-G12-MM-W66A	3/4" BSP TO 3/4" BSP MALE/MALE	
42	ADP-SE90-G-08-MF-W66A	90 DEGREE ADAPTOR	
43	ADP-SE90-G12-MF-W66A	90 DEGREE ADAPTOR	
44	1/2" BSP X 1/2" BSP M/F FIXED	FIXED STRAIGHT BUSH	
45	S6-PP-45-D	1-2" BONDED WASHER	
46	S6-PP-45-F	3-4" BONDED WASHER	
47	19984-H01	1" 2SSK 2850mm 28L STR 28L STR	Г
48	19984-H02	1" 2SSK 2585mm 28L STR 28L STR	Г
49	19984-H03	3/4" 2SSK 2420mm 22L STR 22L STR	Т
50	19984-H04	3/4* 25SK 2605mm 22L STR 22L STR	
51	19984-H05	3/8" 25SK 610mm 12L STR 12L 90	Г
52	19984-H06	3/8" 25SK 690mm 12L 90 12L STR	
53	19984-P01	28x2 C6F 185L	Т
54	19984-P02	22x2 C6F 113L	
55	19984-P03	18x1.5 C6F 139	Г
56	WSHMPA008C	M8 PLAIN WASHER FORM A	Т
57	WSHMPA010C	M10 PLAIN WASHER FORM A	2
58	WSHMPA012C	M12 PLAIN WASHER FORM A	
59	WSHMSQ012C	M12 SPRING WASHER	
60	MCB-10040R	M10x40 HEX BOLT	1
61	MCSD08025R	M8x25 BUTTON HEAD SOCKET SCREW	
62	MSCA08070R	M8x70 CAP HEAD	Н
63	ISO 4762 M12 x 30 — 30N	M4x20 CAP HEAD	
64	MSCA12070R	M12x70 CAP HEAD	Н
		M8x20 COUNTERSUNK	Н
45	MCSC08020R		
65 66	MCSC08020R NUTMCN008T	M8X20 COUNTERSUNK M8 NYLOC	







11. Appendices

11.1. Hot Tapping Data Sheet

Customer DetailsContact Details	
Tap Details. Tap Size Flange Rating Orientation Branch wall Thickness Valve Type Bore Details.	7 1
Flow rateCustor Recommended Flow rates, Gas 20mph; 30fps; 10m/s.	ner Signature Liquids 10mph; 15fps; 5m/s.
Tapping Machine Operational Checks. Tapping adapter bolts secure	Boring Bar Alignment Check.
Check Boring bar is central to Hot Tapping	g Adapter Y/N
Hot Tapping operation Dimensions.	
A, Flange to pipe = B, Top valve to gate = C, Pilot drill to flange = D, Cutter to flange =E, Coupon cut depth =	
Hot Tapping Cutting Distances.	
Pilot Drill to pipe, A+C =	
Valve Details.	
Valve Flange to Gate B = Number of turns to close / open	
E	
Technician SignatureCust Date	omer Signature Date



11.2. Recommended torque settings for fasteners

Thread Ø	Tensile Strength kN	lbs	Torque Setting Nm	in - lbs
M3	6.54	1470	2.1	19
M4	11.4	2560	4.6	41
M5	18.5	4160	9.5	85
M6	26.1	5870	16	140
M8	47.6	10700	39	350
M10	75.4	17000	77	680
M12	110	24700	135	1200
M14	150	33700	215	1900
M16	204	45900	330	2900
M20	306	68800	650	5750
M22	374	83950	875	7725
M24	441	99100	1100	9700
M30	701	158000	2250	19900
M32	860	193500	3050	27000
M36	1020	229000	3850	34100




11.3. Ladder (Optional Accessory)

(The images below are a representation only. The supplied assembly may vary)

The ladder assembly is not supplied as standard. It is available to be purchased as an optional accessory to the hot tapping machine if required.

The ladder assembly attaches to the machine and is used for access to the controls positioned at height. The ladder features attachments for the measuring rod which stores the bar whilst installing the machine and ladder assembly to the pipeline. Once the machine is in position to commence drilling, the measuring rod is easily accessed from the ladder platform and slotted into the machine.



- When standing on the platform, the safety chain must be clipped-on to close the open area at all times.
- Wear suitable footwear to prevent slipping.
- Ensure all bolts connecting the ladder assembly to the machine are correctly tightened to allow a permanent and secure connection of the ladder.
- A suitable fall arrest / harness is recommended when operating the machinery at height.

Issue Date: 13.06.2013



• Do not lean or stretch over the platform barriers.

Doc: MML265 Issue: 004




CAUTION

- When attaching ladders to the machine, never rest the full weight of the machine on to the ladders. The ladder assembly is not designed to be a resting point for the machine.
- Do not carry loose hand tools when climbing the ladders.
- Do not use the ladders or platform to perform maintenance to the machine. The ladder
 assembly has been designed to provide access to the machine control areas only, and not
 for maintenance or repairs of the machine.

11.3.1. Installation


- 1. Carry out a visual inspection of the ladder assembly to ensure it is in a suitable condition for its duty.
- 2. Set down the ladder assembly onto firm level ground. The mounting holes must be facing upwards.



3. Introduce the machine to the ladder assembly. The machine should be suspended horizontally using a suitable lifting device (crane). At no time should the full weight of the machine be loaded onto the ladder assembly. Failure to adhere to this may cause structural damage to the ladder assembly. The ladder assembly is not designed to take the full weight of the machine.




4. If the ladder assembly is supplied with ladder mounting brackets (as shown below), then fit the brackets first to the machine. Follow the platform assembly drawing for the correct placement of the brackets.



(Machine shown is a representation only)

5. Whilst the machine is suspended and touching the ladder, attach all the bolts and tighten them to firmly secure the ladder to the machine. Refer to section 11.2 for torque values.
Caution: Finger trap hazard – pay close attention when installing the mounting bolts and tightening them.



- 6. The machine is now ready to be lifted and installed on to the pipeline.
- 7. To disassemble the ladder assembly from the machine, follow the above procedure in reverse. Never store the machine on the ladder assembly.

Doc: MML265

Issue: 004




11.4. Skid (Optional Accessory)

(The images below are a representation only. The supplied assembly may vary)

The skid is not supplied as standard. It is available to be purchased as an optional accessory to the hot tapping machine if required.

The skid provides the machine a heavy-duty storage and shipping platform and features a dedicated place to store and clamp the measuring rod. It also serves as a platform when mounting the cutter housing onto the machine. There is a bolted toolbox to store tools and other small parts. Forklift pockets and lifting lugs are supplied on the skid for easy manoeuvrability.



Toggle clamp for measuring bar



Crushing/ trapping/ shearing hazard when lowering the machine into the skid vee. Stay clear
from the machine when it is being lowered. Only approach the assembly once the machine is
fully lowered and resting on the vees, to install the U-bolts to strap down the machine.



- Do not climb or stand on the skid. The skid surfaces have not been designed for such activity.
- When lowering the machine, make sure the machine is correctly aligned with the Vees to prevent any damage to the machine components.


Doc: MML265

Issue: 004




11.4.1. Installation

- 1. Carry out a visual inspection of the skid to ensure it is in a suitable condition for its duty.
- 2. Set down the skid onto firm level ground.
- 3. Lower the machine in a horizontal orientation to the skid. Make sure the machine is aligned to the skid so that no machine parts will accidently clash with the skid structure.



4. Place the machine onto the vees and fit the two U-Bolts over the machine to the skid. Ensure that the machine is rigidly secured to the skid.




- 5. Remove the lifting slings from the machine.
- 6. Place the measuring rod into its dedicated position within the skid and operate the toggle clamps to secure it in place.

Doc: MML265

Issue: 004




7. The machine and skid assembly are now ready to be transported or stored. Always use the skid lifting points or forklift pockets to move the unit. Do not use the machine lifting points to lift when the machine is attached to the skid.



8. To disassemble the machine from the skid, follow the above procedure in reverse.

Using the skid to install the cutter housing / adapter flange

Before installing the cutter housing, ensure that the machine and skid assembly is situated on firm level ground. The machine should be secured to the skid and positioned at a height so that the flange adapter will not clash on the ground when it is being installed to the machine. Refer to section 5.1 for installation information.




Doc: MML265

Issue: 004




11.5. Alternative Gearbox assembly (MHT1242-34)



Doc: MML265 Issue: 004 Issue Date: 13.06.2013



11.6. Hydraulic schematic diagram





11.7. **General Notes**